

CATEK RS/FRS Binding Spacers

Hardware Information

Use the proper mounting hardware!

It is imperative that you use the appropriate mounting hardware for your binding/spacer/board combination.

The CATEK RS & FRS Binding Spacers are 4.75mm (3/16-inch) thick, so you will need to use mounting hardware that is longer than your standard binding to board mounting hardware. CATEK OS2 & FR2 users please see the chart below.

Binding	No Spacer	With Spacer
CATEK OS2 w/Standard Elastomer	12mm	16mm
CATEK OS2 w/D3 Elastomer	14mm	18mm
CATEK FR2 w/D3 Elastomer	14mm	18mm

Non-OS2/FR2 users must add the spacer thickness to the manufacturer's recommended screw length. Standard M6 screw lengths are 12mm, 14mm, 16mm, 18mm, 20mm, and 25mm. The correct screw length for your bindings may require grinding the screw to the proper length.

An absolute minimum of **3 full threads** of screw thread engagement into the snowboard inserts is necessary. Be sure to account for insert depth below board surface.

CATEK recommends M6 screws made from A2 (304) or A4 (316) stainless steel.

